




Maintenance Parts


Follow the steps below for replacement.
Reassemble in reverse order once complete.



1. Open the tailgate and remove the access cover on the right side.




2. The rear cabin air filter is located as shown in the illustration.




3. Insert your finger into the hole and hook it onto the loop at the top of the cover.



4. Press the upper hook of the filter cover to release and open it.



5. Grasp the edge of the filter and pull it straight out.



6. It is likely to be full of dust and dirt, so be careful and make note of the direction of airflow as indicated by the arrow on the side of the old filter.

Ensure the filter is installed in the correct direction. Handle with care to avoid damaging surrounding parts. Incorrect installation may result in abnormal noise and reduced filtration efficiency.

PREMIUM CABIN AIR FILTER / CABIN AIR FILTER

Installation & Replacement Guide

Carnival(Rear)

- See the application chart for vehicle years -



Maintenance Parts